

MODELS A, B, C AND S PNEUMATIC ACTUATORS

OPERATION AND MAINTENANCE INSTRUCTIONS

INTRODUCTION

General application

Actuators are designed for 'on-off' or modulating control of any quarter-turn ball, butterfly, rotary plug or damper style valve application.

Technical data

Supply pressure: 2.75 - 11 bar (40 - 160 psig), see product nameplate
 Supply medium: any pneumatic fluid compatible with materials of construction
 Temperature rating: standard range: -28°C to +98°C (-20°F to +210°F)
 optional range: -54°C to +149°C (-65°F to +300°F)
 Angular rotation: 90 degrees ± 8 degrees

1. INSTALLATION

The actuator can be mounted parallel or perpendicular to pipeline. The actuator can be installed in any convenient position including vertical, horizontal or upside down.

- A. Bolt mounting bracket to actuator hand tight. DO NOT tighten yet.
- B. Install coupling on valve. Be sure rotary stops on valve are removed or adjusted to allow actuator stops to do the stopping.
- C. Install actuator and bracket to valve being sure to leave all fastener connections hand tight. If possible, stroke valve and actuator to a half open position 45° and physically shift actuator back and forth until coupling and all fasteners are relaxed then tighten all bolts and nuts. This procedure will accurately align valve stem to actuator output shaft and prolong valve stem seal life.

- D. Cycle valve / actuator assembly and observe for smooth operation.
- E. Adjust travel stops for perfect alignment in both open and closed positions.
Note: If jackscrew override is installed, please refer to section 2B for stroke adjustment.
- F. Tubing connections - some models utilize two pistons for added power. Spring return (single acting) dual cylinders designs require one 'jumper' to make the supply port common on both pistons. Double acting (air to air) dual cylinder designs require two 'jumpers.' See Figure 1 for typical arrangement.


CAUTION

Use correct length mounting bolts! Mounting bolts used in actuator mounting pad may interfere with the actuator rotary mechanism. Select bolts that will not extend more than two threads above the back of the mounting pad.

2. MAINTENANCE

Actuators are factory lubricated and in general do not require periodic lubrication or maintenance while in service. Actuators should be visually inspected periodically for corrosion damage and promptly repaired. Actuators should be operated at least annually to assure proper operation.

FIGURE 1 - MODELS A, B, C AND S



MODELS A, B, C AND S PNEUMATIC ACTUATORS

OPERATION AND MAINTENANCE INSTRUCTIONS

3. JACKSCREW OVERRIDE

The jackscrew option is intended for infrequent or emergency on-site operation of the automated valve.

Jackscrew operating instructions

1. Disengage power supply and vent air from actuator.
2. Operate the handwheel to drive the actuator into the desired position. Valve position can be verified by checking the actuator position indicator. For models 006 through 270, the jackscrew must be returned to the fully retracted position before actuator can resume normal operation. Back the jackscrew out until it stops. Air will leak from the jackscrew unless it has been fully retracted against its internal seal.

Actuator stroke adjustment

(The jackscrew has a built-in actuator stroke adjustment.)


Models 006 through 270 (see Figure 2)

1. Retract the jackscrew override completely by rotating counter clockwise.
2. Loosen the lock nut and turn the brass adjusting screw to the desired position. The handwheel will rotate with the adjusting screw. Never make stroke adjustments by turning the handwheel only.
3. Tighten lock nut.

Models 370, 740 and 575 (see Figure 3)

1. Retract the jackscrew override completely by rotating clockwise.
2. Loosen the stroke adjusting screw and lock nut.
3. Using the handwheel, turn the jackscrew to adjust the actuator to the desired position.
4. Screw the adjusting screw until it stops and tighten lock nut.

FIGURE 2 - JACKSCREW OVERRIDE - MODELS 006 THROUGH 270



MODELS A, B, C AND S PNEUMATIC ACTUATORS

OPERATION AND MAINTENANCE INSTRUCTIONS

FIGURE 3 - JACKSCREW OVERRIDE - MODELS 370, 575 AND 740





FIGURE 4 - HYDRAULIC OVERRIDE



MANUAL HANDPUMP SPECIFICATIONS


1. Maximum reservoir fill volume = 1.23 dm³ (75 in³)
2. Pump relief pressure = 103 bar (1500 psi)
3. Pump volume/stroke = 0.01 dm³ (0.66 in³)
4. Handle length = 610 mm (24 in)

MODELS A, B, C AND S PNEUMATIC ACTUATORS

OPERATION AND MAINTENANCE INSTRUCTIONS


Single acting spring return two pistons

Models: 012, 046, 058, 059, 072, 100, 144, 270, 344, 345, 420, 740, 944, 945, 1150, 1480, 1929, 1930, 2380




Single acting spring return one piston

Models: 003, 006, 015, 023, 036, 050, 135, 210, 370 and 575




Double acting air to air two pistons

Models: 012, 059, 072, 100, 144, 270, 345, 420, 740, 945, 1150, 1480, 1930, 2380



Double acting air to air one piston

Models: 003, 006, 015, 023, 036, 050, 135, 210, 370, 575



SECTION A - A, MODELS 003-1150


SECTION A - A, MODELS 135-1150

MODELS A, B, C AND S PNEUMATIC ACTUATORS

OPERATION AND MAINTENANCE INSTRUCTIONS


Single acting spring return two pistons

Models: 1485, 1934, 1935, 2385-5336





Single acting spring return two pistons

Models: 6044, 7114




Double acting air to air two pistons

Models: 1485, 1934, 2385-7114



Yoke shown at mid-stroke,
pointer omitted for clarity

SECTION A - A, MODELS 1480-2380



SECTION A - A, MODELS 1485, 1934, 1935, 2385-7114

MODELS A, B, C AND S PNEUMATIC ACTUATORS

OPERATION AND MAINTENANCE INSTRUCTIONS

MATERIALS OF CONSTRUCTION (continued next page)

Item	S material		B material		C material	A material	
	003-100	135-1150	006-100	135-1150	135-1150	006-100	135-420
1 Housing	316 SS	316 SS	Ductile iron	Ductile iron	Ductile iron	Steel	Steel
2 Yoke	17-4 PH	17-4 PH	17-4 PH	17-4 PH	17-4 PH	17-4 PH	17-4 PH
3 Output shaft	17-4 SS	17-4 SS	4140	4140	4140	4140	4140
4 Piston rod	316 SS	316 SS	CPO	CPO	CPO	CPO	CPO
5 Bushing - output shaft	PTFE	PTFE composite	Bronze	PTFE composite	PTFE composite	Bronze	PTFE composite
6a Yoke pin	18-8 SS	-	Steel	-	-	Steel	-
6b Key - yoke	-	17-4 PH	-	Steel	Steel	-	Steel
7 Bushing - piston rod	PTFE	PTFE	Bronze	Bronze	Bronze	Bronze	Bronze
8 Retaining ring - output shaft	15-7 MO	15-7 MO	Steel	Steel	Steel	Steel	Steel
9 Thrust pin	440C SS	440C SS	440C SS	440C SS	440C SS	440C SS	440C SS
10 Roller bearing	440C SS	440C SS	440C SS	440C SS	440C SS	440C SS	440C SS
11 Retaining ring - pin	15-7 MO	15-7 MO	Steel	Steel	Steel	Steel	Steel
12 Seal, thrust plate	-	NBR	-	NBR	NBR	-	NBR
12a Set screw	18-8 SS	-	18-8 SS	-	-	18-8 SS	-
12b Retaining ring - lower bearing	-	18-8 SS	-	Steel	Steel	-	Steel
13 Pointer adaptor	-	Nylon	-	Nylon	Nylon	-	Nylon
13a Position indicator	304 SS	-	-	-	-	-	-
13b Thrust plate	-	316 SS	-	Ductile iron	Ductile iron	-	Steel
13c Gasket, thrust plate	-	Fiber	-	Fiber	Fiber	-	Fiber
14 Hex head bolt	18-8 SS	18-8 SS	18-8 SS	Steel	Steel	18-8 SS	Steel
15 Lock washer	18-8 SS	18-8 SS	18-8 SS	Steel	Steel	18-8 SS	Steel
16 Pointer	Soft PVC	Soft PVC	Soft PVC	Soft PVC	Soft PVC	Soft PVC	Soft PVC
17 Round head screw	18-8 SS	18-8 SS	18-8 SS	Steel	Steel	18-8 SS	Steel
18 Cover - housing	316 SS	316 SS	Steel	Steel	Steel	Steel	Steel
19 Hex head bolt	18-8 SS	18-8 SS	18-8 SS	Steel	Steel	18-8 SS	Steel
20 Lock washer	18-8 SS	18-8 SS	18-8 SS	Steel	Steel	18-8 SS	Steel
21 Pointer washer	18-8 SS	18-8 SS	18-8 SS	Steel	Steel	18-8 SS	Steel
22 Thrust washer	-	18-8 SS	-	Steel	Steel	-	Steel
23 Gasket - cover	Fiber	Fiber	Fiber	Fiber	Fiber	Fiber	Fiber
24 Cylinder	316 SS	316 SS	316 SS	316 SS	Steel /XYLAN	316 SS	Steel /XYLAN
25 Piston	316 SS	316 SS	Ductile iron	Ductile iron	Ductile iron	Steel	Steel
26 Adaptor	316 SS	316 SS	Ductile iron	Ductile iron	Ductile iron	Steel	Steel
27 End cap	316 SS	316 SS	Ductile iron	Ductile iron	Ductile iron	Steel	Steel
28 Rod cover	316 SS	316 SS	Ductile iron	Ductile iron	Ductile iron	Steel	Steel
29 Seal - piston rod	NBR	NBR	NBR	NBR	NBR	NBR	NBR
30 Seal - piston bolt	NBR	NBR	NBR	NBR	NBR	NBR	NBR
31 Seal - piston	NBR	NBR	NBR	NBR	NBR	NBR	NBR
32 Gasket - housing	Fiber	Fiber	Fiber	Fiber	Fiber	Fiber	Fiber
33 Piston bolt	18-8 SS	18-8 SS	18-8 SS	Steel	Steel	18-8 SS	Steel
34 Lock washer	18-8 SS	18-8 SS	18-8 SS	Steel	Steel	18-8 SS	Steel
35 Bearing - piston	PTFE	PTFE	PTFE	PTFE	PTFE	PTFE	PTFE
36 Thread seal	SS/EPDM	SS/EPDM	Steel/NBR	Steel/NBR	Steel/NBR	Steel/NBR	Steel/NBR
37 Travel stop bolt	18-8 SS	18-8 SS	18-8 SS	Steel	Steel	18-8 SS	Steel
38 Jam nut	18-8 SS	18-8 SS	18-8 SS	Steel	Steel	18-8 SS	Steel
39 Socket head cap screw	18-8 SS	18-8 SS	18-8 SS	Steel	Steel	18-8 SS	Steel
41 Tie rod	18-8 SS	18-8 SS	18-8 SS	Steel	Steel	18-8 SS	Steel
42 Seal - output shaft	-	-	NBR	-	-	NBR	-
43 Lock washer	18-8 SS	18-8 SS	18-8 SS	Steel	Steel	18-8 SS	Steel
45 Stato-seal	NBR	NBR	NBR	NBR	NBR	NBR	NBR
46 Cylinder gasket or O-ring	TFE or NBR	NBR	NBR	NBR	NBR	NBR	NBR
47 Label - nameplate	MYLAR	MYLAR	MYLAR	MYLAR	MYLAR	MYLAR	MYLAR
48 Seal - output shaft bushing	-	-	NBR	-	-	NBR	-

MODELS A, B, C AND S PNEUMATIC ACTUATORS

OPERATION AND MAINTENANCE INSTRUCTIONS

MATERIALS OF CONSTRUCTION (continued)

Item	S material		B material		C material	A material	
	003-100	135-1150	006-100	135-1150	135-1150	006-100	135-420
49 Cylinder - spring side	316 SS	316 SS	316SS	316 SS	Steel /XYLAN	316 SS	Steel /XYLAN
50 Tie rod - spring side	316 SS	316 SS	316 SS	Steel	Steel	316 SS	Steel
51 Hex head bolt	18-8 SS	18-8 SS	18-8 SS	Steel	Steel	18-8 SS	Steel
52 Travel stop bolt	18-8 SS	18-8 SS	18-8 SS	Steel	Steel	18-8 SS	Steel
53 Flat washer	18-8 SS	18-8 SS	18-8 SS	Steel	Steel	18-8 SS	Steel
54 End cap - spring side	316 SS	316 SS	Ductile iron	Ductile iron	Ductile iron	Steel	Steel
55 Spring - outer	Steel	Steel	Steel	Steel	Steel	Steel	Steel
56 Spring - inner	Steel	Steel	Steel	Steel	Steel	Steel	Steel
57 Breather	18-8 SS	18-8 SS	Steel	Steel	Steel	Steel	Steel
58 Label - spring	LEXAN	LEXAN	LEXAN	LEXAN	LEXAN	LEXAN	LEXAN

MATERIALS OF CONSTRUCTION (continued next page)

Item	S material	Item	B material	C material
	1480-2380		1480-2380	1480-2380
1 Housing	316 SS	1 Housing	Ductile iron	Ductile iron
2 Yoke	17-4 PH	2 Yoke	Ductile iron	Ductile iron
		3 Guide block	Ductile iron	Ductile iron
		4 Piston rod - left	CPO	CPO
		4a Piston rod - right	CPO	CPO
4 Piston rod	316 SS	4b Jam nut - piston rod	Steel	Steel
5 Bearing - yoke	PTFE composite	5 Bearing - yoke	PTFE composite	PTFE composite
		6 Bearing - thrust pin	Steel	Steel
		6a Bearing - guide bar	Steel	Steel
		6b Thrust bearing - thrust pin	Nylon	Nylon
7 Bushing - piston rod	Bronze	7 Bushing - piston rod	Bronze	Bronze
		8 Guide bar	CPO	CPO
9 Thrust pin	440C SS	9 Thrust pin	440C SS	440C SS
10 Slide block	Bronze	10 Seal, bearing	NBR	NBR
11 Retaining ring - pin	15-7 MO	11 Retaining ring - accessory drive	Steel	Steel
12 Plug - thrust pin access	18-8 SS	12 Seal - guide bar	NBR	NBR
		12a Seal, cap	NBR	NBR
		12b Seal, accessory drive	NBR	NBR
13 Pointer adaptor	Nylon	13 Accessory drive	Steel	Steel
14 Drive bar	Steel	14 Drive bar	Steel	Steel
15 Screw, accessory drive	Steel	15 Cap	Ductile iron	Ductile iron
16 Pointer	Soft PVC	16 Pointer	Soft PVC	Soft PVC
17 Round head screw	18-8 SS	17 Round head screw	18-8 SS	Steel
18 Cover - housing	316 SS	18 Cover - housing	Ductile iron	Ductile iron
19 Hex head bolt - cover	18-8 SS	19 Hex head bolt - cover	Steel	Steel
20 Lock washer - cover	18-8 SS	20 Lock washer - cover	Steel	Steel
21 Pointer washer	18-8 SS	21 Pointer washer	Steel	Steel
22 Vent valve	Brass	22 Vent valve	Brass	Brass
		23 Cup, spring	Ductile iron	Ductile iron
24 Cylinder	316 SS	24 Cylinder	316 SS	Steel / XYLAN
25 Piston	316 SS	25 Piston	Ductile iron	Ductile iron
26 Adaptor	316 SS	26 Adaptor	Ductile iron	Ductile iron
		26a Spacer plate (1485-2385 only)	Ductile iron	Ductile iron
27 Endcap	316 SS	27 Endcap	Ductile iron	Ductile iron
28 Rod cover	316 SS	28 Rod cover	Ductile iron	Ductile iron
29 Seal - piston rod	NBR	29 Seal - piston rod	NBR	NBR
30 Seal - piston bolt	NBR	30 Seal - piston bolt	NBR	NBR
31 Seal - piston	NBR	31 Seal - piston	NBR	NBR
32 Gasket - housing	Fiber	32 Gasket - housing	Fiber	Fiber
33 Hex head bolt - piston	18-8 SS	33 Hex head bolt - piston	Steel	Steel
34 Lock washer - piston	18-8 SS	34 Lock washer - piston	Steel	Steel
35 Bearing - piston	PTFE	35 Bearing - piston	PTFE	PTFE
36 Thread seal	SS/EPDM	36 Thread seal	Steel/EPDM	Steel/EPDM

MODELS A, B, C AND S PNEUMATIC ACTUATORS

OPERATION AND MAINTENANCE INSTRUCTIONS

MATERIALS OF CONSTRUCTION (continued)

Item	S material	Item	B material	C material
	1480-2380		1480-2380	1480-2380
37 Travel stop bolt	18-8 SS	37 Travel stop bolt	Steel	Steel
38 Jam nut	18-8 SS	38 Jam nut	Steel	Steel
39 Socket head cap screw	18-8 SS	39 Socket head cap screw	Steel	Steel
41 Tie rod	18-8 SS	41 Tie rod	Steel	Steel
42 Seal - yoke	NBR	42 Seal - yoke	NBR	NBR
43 Lock washer	18-8 SS	43 Lock washer	Steel	Steel
44 Hex head bolt	18-8 SS	44 Hex head bolt	Steel	Steel
45 Stato-seal	NBR	45 Stato-seal	NBR	NBR
46 Cylinder O-ring	NBR	46 Cylinder O-ring	NBR	NBR
47 Label - nameplate	MYLAR	47 Label - nameplate	MYLAR	MYLAR
48 Seal - output shaft bushing	NBR			
49 Cylinder - spring side	316 SS	49 Cylinder - spring side	316 SS	Steel / XYLAN
50 Tie rod - spring side	316 SS	50 Tie rod - spring side	Steel	Steel
51 Hex head bolt	18-8 SS	51 Hex head bolt	Steel	Steel
52 Travel stop bolt	18-8 SS	52 Travel stop bolt	Steel	Steel
53 Flat washer	18-8 SS	53 Flat washer	Steel	Steel
54 Endcap - spring side	316 SS	54 Endcap - spring side	Ductile iron	Ductile iron
55 Spring - outer	Steel	55 Spring - outer	Steel	Steel
56 Spring - inner	Steel	56 Spring - inner	Steel	Steel
57 Breather	18-8 SS	57 Breather	Steel	Steel
58 Label - spring	LEXAN	58 Label - spring	LEXAN	LEXAN

4. MANUAL HANDPUMP HYDRAULIC OVERRIDE (see Figure 4)

- A. Maintain fluid level to fill line using ISO-22 hydraulic fluid. Use Chevron 'Hydraulic Oil AW' or equal.
- B. The selector control valve is set in center position for remote operation. Select left or right positions for manual open or manual close as shown on pump label.
- C. Store and lock handle to keep pump plunger closed. Do not remotely operate actuator with handle on plunger.

Hydraulic fluid level

The fluid level in the handpump reservoir changes when the actuator is operated. The fluid level is high when the hydraulic cylinder piston rod is retracted into the hydraulic cylinder. The fluid level is low when the hydraulic cylinder piston rod is extended out of the hydraulic cylinder. Measure the fluid level in the low position, using a dip stick, and maintain this level as shown on the sticker (25.4 mm [1 inch] above the pump base). Operate the actuator open and closed and view the fluid level to verify where the low position is. Be sure to tighten the fill port plug securely.

CAUTION: Do not exceed this fluid level or fluid may squirt out of the relief valve.

Remote mounting the handpump

The handpump is normally installed on the actuator with the fill port on top. When installed on a valve in a pipeline, the fill port must remain on top regardless of the angle of the valve in the pipeline. This may require the handpump to be reinstalled in the field.

The handpump can be remote mounted on an adjacent structure. The optimum position is close to and above the actuator. If the handpump is located below the actuator, BOTH speed control valves must be completely closed before removing the reservoir fill plug to check the fluid level. This will prevent hydraulic fluid from draining out of the actuator. Reset both speed controls after the fill plug is reinstalled.

5. INTEGRAL PROXIMITY SWITCH MOUNTING (Only with Prox Prep factory ordered option)

- A. Remove plastic plugs from proximity ports located on the back of the actuator housing.
- B. Insert switch and turn clockwise until switch touches ferrous activator on yoke, then back off approximately 1.6 mm (1/16").
- C. Test switch by stroking actuator and verifying make and break of switch.
- D. Repeat procedure for second switch if required.

MODELS A, B, C AND S PNEUMATIC ACTUATORS

OPERATION AND MAINTENANCE INSTRUCTIONS

6. SPRING CONVERSION TO CHANGE OPERATING PRESSURE

All spring packs except the 2.8 bar (40 psi) consist of an inner and outer spring. The 2.8 bar (40 psi) spring pack uses an outer spring only. Various spring packages are available upon request from the factory.

CAUTION

Before attempting spring conversions always be sure that spring is in the 'failed' or extended position. Remove any accessory equipment that may cause the spring to be cocked (e.g.: declutchable override, jackscrew override, etc.).

- A. Back off adjustable travel stop on end of actuator opposite spring end. This will allow maximum spring extension inside the actuator.

(Models S-003 and B-006 only)

- B. Remove tie rod bolts (41). Back off piston bolt (33) until spring is fully relaxed and piston (25) is free.
- C. Remove 5.5 bar (80 psi) spring package and replace with desired spring package.
- D. Re-assemble piston, cylinder, endcap and tie rods, being sure to follow the tie rod tightening sequence (Figure 8). Do not over tighten bolts. Refer to Assembly torque requirements chart (Table 1).

(All models except S-003 and B-006)

- B. Alternately and uniformly remove bolts (51) from hollow tie rods. Back off each bolt approximately 6.4 mm (1/4"), following the tie rod sequence (Figure 8). Repeat the sequence until spring(s) is/are totally relaxed and endcap is free.
- C. Remove 5.5 bar (80 psi) spring package and replace with desired spring package.
- D. Re-assembly endcap with bolts (51). Use reverse procedure as shown in step B, being sure to follow the tie rod tightening sequence (Figure 8). Be sure each hollow tie rod slides into the counterbore in endcap. Do not over tighten bolts. Refer to Assembly torque requirement chart (Table 1).
- E. Remove nameplate from actuator and stamp or etch correct spring pressure rating accordingly.

7. FAILURE MODE CHANGE

(Models 003-100 and 144) Symmetric yoke actuators only

Conversion from 'fail close' to 'fail open' is accomplished by flipping the actuator over (i.e. left to right). The top and bottom of the center housing have identical mounting flanges and output shaft dimensions. Remove the vinyl pointer and indicator plate and mount them on opposite side of actuator.

(Models 023-7114) Canted and symmetric yoke actuators (except noted above)

Conversion requires removal of the spring cylinder assembly and reinstallation on the other side of the housing. It is recommended that fail open and fail closed be ordered from the factory.

8. REMOVAL OF ACTUATOR FROM VALVE

CAUTION

Do not attempt to remove mounting bolts between actuator and valve until supply pressure has been disconnected and vented. If spring return, be sure that valve is completely in failed position. If valve is frozen in a position causing the spring to be cocked, removal of bracket bolts would allow spring to stroke, resulting in the actuator rotating over bracket causing possible injury or damage.

- A. Loosen bracket to actuator bolts to hand tight position.
- B. Physically shift actuator back and forth to be sure there is no strain (or shear stress) on the bracket bolts. Once it has been determined that there is no pressure or spring coil remaining in the actuator, remove bolts and remove actuator and coupling from valve.
- C. In the event the valve is frozen or locked in place, resulting in spring energy remaining in the actuator, replace adjusting screw (37) on end of actuator opposite spring end with length of 'all thread' rod of sufficient length and turn clockwise until it contacts the piston. This procedure will safely secure the piston and spring assembly and allow actuator removal. Be sure to remove 'all thread' rod prior to actuator disassembly.

MODELS A, B, C AND S PNEUMATIC ACTUATORS

OPERATION AND MAINTENANCE INSTRUCTIONS

9. DISASSEMBLY

DISASSEMBLY OF SYMMETRIC YOKE ACTUATORS

- A. Remove endcap(s) (27); tie rods (41) and cylinder (24). Remove rod cover (28) if applicable.
- B. Remove piston bolts (33) and pistons (25) and springs if applicable (55 and 56).
- C. Remove adaptor (26) and piston rod seals (29).

Note: S-003, B-006 and B-015 have one piece cast housing / adaptor.

- D. Remove nameplate (18), pointer (16) and position indicator (where applicable) (13).

(Models 003-100 and 144)

- E. Disengage yoke (2) from roller bearing assembly by pulling piston rod to extreme right, as in Figure 5, and swing yoke mechanism clear of roller bearing as in Figure 6.
- F. Rotate piston rod 90° to allow access to retaining ring (11) as shown in Figure 7.
- G. Remove retaining ring and bearing (10). Then rotate piston rod (4) 180° and remove the bearing and thrust pin assembly.
- H. Remove piston rod (4) and piston rod bushings (7).
- I. Remove plug (12) from back of housing.
- J. Using a punch or suitable dowel pin, insert through clearance hole and press yoke pin (6) out.
- K. Remove retaining ring (8) from output shaft. Remove output shaft and yoke.
- L. Remove bushings (5) from housing.

(Models 135, 270-1150)

- E. Disengage yoke (2) from roller bearing assembly by pulling piston rod (4) to extreme right, as in Figure 5, and swing yoke (2) clear of roller bearing (10) assembly. See Figure 6.
- F. Rotate piston rod (4) 90° to allow access to retaining ring (11) as shown in Figure 7.
- G. Remove the thrust pin retaining rings (11) and withdraw the roller bearings (10), and thrust pin (9).
- H. Remove piston rod (4) and piston rod bushings (7).
- I. Remove retaining rings (8) and (12b) on both ends of output shaft.
- J. Remove thrust plate (13b) and thrust washers (22) from the output shaft (3).
- K. Position the yoke (2) in the fully clockwise position (viewed from the thrust plate (13b) side).
- L. Using a soft hammer, drive output shaft (3) out through top of housing (1).
- M. Withdraw yoke (2) from housing (1).
- N. Remove the output shaft bushings (5) from the housing (1).

(Models 1480, 1929, 1930, 2380)

- E. Remove the pointer (16) and accessory drive (13) from the actuator by removing the screw (14) from inside the yoke (2) bore.

- F. Remove all cover bolts (19). Three of these bolts occupy 'jack bolts' holes and are threaded into the cover (18). Screw three long cover bolts into these 'jack bolt' holes and turn them sequentially ½ turn at a time to pry the cover off. See Figure 6A.
- G. Remove the thrust pin access plug (12). (Figure 5A)
- H. Push the yoke (2) using the piston rod (4) until the thrust pin (9) is centered over the thrust pin access hole (See Figure 5A). Remove the upper thrust pin retaining ring (11) from the thrust pin (9) (Figure 7A).
- I. Push the thrust pin (9) and lower retaining ring (11) out through the thrust pin access hole allowing the slide blocks (10) to fall free. Remove the slide blocks (10).
- J. Remove the piston rod (4), piston rod bushings (7), yoke (2). Remove yoke bearings (5), and yoke seals (48) from the housing (1) and cover (18). Remove the upper and lower vent valves (22) from the back of the housing.

(Models 1485, 1934, 1935, 2385-7114)

- D. Remove adaptor spacer (26a) (installed on models 1485-2385 only, see Figure 7B).
- E. Remove cap (15) by removing the cap bolts (15a).
- F. Remove all cover bolts (19) and cover (18). Three of these bolts occupy 'jack bolt' holes and are threaded into the cover (18). Screw three long cover bolts into these 'jack bolt' holes and turn them sequentially ½ turn at a time to pry the cover off. See Figure 6B.
- K. Swing the yoke (2) to one side to expose the guide block (3).
- L. Unscrew the piston rod jam nuts (4b) and remove the piston rods (4 and 4a).
- M. Remove the guide bar (8), guide block(3) and yoke (2).
- N. Remove the yoke bearings (5).

FIGURE 5




FIGURE 6





FIGURE 7



MODELS A, B, C AND S PNEUMATIC ACTUATORS

OPERATION AND MAINTENANCE INSTRUCTIONS

DISASSEMBLY OF CANTED YOKE ACTUATORS

Canted yoke actuators are disassembled the same way as the symmetric yoke actuators except for the following additional instructions for specific models:

(Models 023-100)

These actuators are disassembled using the same procedure as the symmetric actuators. However, the thrust pin (9) is removed from the housing (1) via access plugs on the upper and lower housing mounting flanges.

(Models 135-1150)

- F. Remove the pointer (16), pointer adaptor (13) and pry out the thrust plate seal (12) (if fitted).
- G. Remove the thrust plate (13b) and thrust washers (22) from the output shaft (3).
- H. Position the yoke (2) in the fully clockwise position (viewed from the thrust plate (13b) side).
- I. Using a soft hammer, drive output shaft (3) out through the thrust plate side of the housing (1). This will drive out the upper output shaft bushing (5) and yoke key (6b).
- J. Remove the piston rod bushings (7) from the housing (1).
- K. Shift the yoke (2) around in the housing (1) so that the thrust pin (9) and roller bearing (10) assembly can be moved out of the yoke slot. Remove the thrust pin retaining rings (11) and withdraw the roller bearings (10), thrust pin (9), piston rod (4) and yoke (2).
- L. Remove the lower output shaft bushing retaining ring (12b) and lower output shaft bushing (5).

10. ASSEMBLY

ASSEMBLY OF SYMMETRIC YOKE ACTUATORS

(Models 003-100 and 144)

- A. Insert piston rod bushings (7) and output shaft bushings (5) in housing. (On models B-006 through 100 lube output shaft bushings O-rings (48) with 'Dow Corning #112' lubricant. Push one O-ring halfway on each bushing and install bushings in housing.)
- B. Place yoke (2) in position in housing. Lubricate with WD-40 or similar lubricant and install output shaft (3). (On models B-006 through 100, lube output shaft O-rings (42) with 'Dow Corning #112' lubricant. Install one O-ring on one end of output shaft and insert through housing and yoke. Install second O-ring on opposite end of output shaft and push output shaft back into housing.) Secure output shaft with retaining rings (8).
- C. Lubricate and press yoke pin (6) into yoke and output shaft assembly from open side of housing. Be sure pin is pressed flush in yoke to prevent interference with piston rod (4).

(Models 135, 270-1150)

- A. Insert yoke key (6b) into output shaft (3).
- B. Install yoke (2) in housing (1). Slide output shaft (3) through top of housing (1) into the yoke (2). Install lubricated upper and lower bearings (5a).
- C. Install lower thrust washer (22), thrust plate (13), upper thrust washer (22) and retaining ring (8). Install lower bearing retaining ring (12b).

(Models 003-1150)

- D. Lubricate with WD-40 and install piston rod (4) being careful not to scratch sealing surfaces when sliding through yoke assembly.
- E. Swing yoke clear toward left side of housing as shown in Figure 7.
- F. Sub-assemble thrust pin (9) with one roller bearing (10) and one retaining ring (11). Pre-lubricate sub-assembly with high temperature grease such as 'Whitmore's Omnitemp II'.
- G. Install roller bearing sub-assembly per Figure 7. Rotate piston rod 180° and assemble second roller bearing and retaining ring. Place ample amount of high temperature grease on roller bearing and inside wear area of yoke.
- H. Engage roller bearing in yoke assembly as shown in Figure 7, 6 and 5.
- I. Install plug (12) in back of housing if applicable. Use 'Loctite 222 Thread Locker'.

FIGURE 5A




FIGURE 6A




FIGURE 7A





FIGURE 6B



MODELS A, B, C AND S PNEUMATIC ACTUATORS

OPERATION AND MAINTENANCE INSTRUCTIONS

(Models 1480-2380)

- A. Install yoke seals (42) using O-ring lube and yoke bearings (5) using WD-40 into the cover (18) and housing (1).
- B. Inspect the housing upper and lower vent passages and clear any blockage. Install new vent valves (22).
- C. Lubricate the bearing surfaces of the yoke (2) with WD-40 and install the yoke (2) in the housing (1). Install the yoke with the marking and the pointer drive bar visible through the cover hole.
- D. Install the piston rod bushings (7) and the piston rod (4).
- E. Install the lower retaining ring (11) on the thrust pin (9) and lubricate the pin with Whitmore grease. Lubricate the slide blocks (10) with Whitmore grease inside and out and position them in the yoke (2) slots. Insert the thrust pin (9) through the thrust pin access hole (Figure 6A) and slide it through the lower slide block (10), piston rod (4), and upper slide block (10). Install the upper retaining ring (11) on the thrust pin (9).
- F. Place joint compound on the sealing surface of the cover (18), install the cover on the housing (1), and torque the cover bolts (19) to 41 Nm (30 ft-lb). Install the short cover bolts (19) into the jack bolt holes of the cover (18).


(Models 1485-7114)

- A. Install new guide bar bearing (6a) and thrust pin bearings (6b) in the guide block (3).
- B. Install new yoke bearings (5) and thrust bearings (6) in housing (1) and cover (18). Position the bearing seal (10) in the yoke bearings (5) toward the inside of the housing (1).
- C. Use Valvoline multi-purpose grease /GM (or equal) to lubricate all bearings including a generous amount on the thrust bearings (6).
- D. Insert the yoke (2) into the housing (1).
- E. Insert the guide block (3) into the housing (1) and slide the guide bar (8) through the housing (1) and through the guide block. Install the guide bar seals (12), lubricate the seals with grease, and then finish sliding the guide bar into the housing.
- F. Install the piston rod bearings (7) in the housing (1).
- G. Install the jam nuts (4b) on the piston rods (4) and (4a) and install the piston rods. Symmetric yoke piston rods are equal length and can be installed on either side. See Figure 7C.
- H. Swing the yoke (2) over the guide block (3) and install the thrust pin (9).
- I. Insert a bead of Dow Corning 732 silicone sealant on the cover (18) sealing surface and install the cover (18) on the housing (1) torquing the bolts to 8 Nm (6 ft-lb).
- J. Install the cap seal (12a) and cap (15).


(Cylinder and rod cover assembly - all models)

- J. Assemble bolt (33) on end of piston rod before installing rod cover when rod cover is required.
- K. Install rod cover (28) if applicable. Actuators utilizing one piston only require a rod cover. Bolt rod cover and gasket in place with socket head screws (39). Use 'Locktite 222 Thread Locker'.
- L. For models 1485-3072 install the piston rod spacer plate.
- M. Assemble piston rod O-ring (29) on piston rod. Lubricate O-ring with 'Dow Corning #112' lubricant.

FIGURE 7B




CANTED YOKE ACTUATOR




SYMMETRIC YOKE ACTUATOR

FIGURE 7C

The canted yoke piston rod is not symmetrical. It must be positioned as shown. The symmetrical yoke piston rod can be installed either way.



CANTED YOKE ACTUATOR
Closed position - top view



SYMMETRIC YOKE ACTUATOR
Open position - top view



MODELS A, B, C AND S PNEUMATIC ACTUATORS

OPERATION AND MAINTENANCE INSTRUCTIONS

TABLE 1 - ASSEMBLY TORQUE REQUIREMENTS (Nm)

Model no.	Adaptor bolt (44)	Piston bolt (33)	Tie rod (33)	Tie rod bolt spring side (51)
003	N/A	20.3	13.6	N/A
B-006	N/A	20.3	20.3	N/A
015	N/A	20.3	40.7	33.9
S-006, 012	20.3	20.3	20.3	13.6
023 thru 100	40.7	54.2	40.7	33.9
135, 270	203.4	203.4	203.4	135.6
344	203.4	203.4	339.0	135.6
345	203.4	203.4	203.4	339.0
210, 420	203.4	203.4	339.0	339.0
370, 575 thru 2380	339.0	339.0	339.0	339.0

FIGURE 8 - TIE ROD TIGHTENING SEQUENCE



- N. Assemble adaptor (26) to housing using gasket (32) between adaptor and housing. If actuator is spring return model be sure to insert long tie rod bolts (51) with washer into adaptor prior to bolting adaptor to housing. Secure the adaptor (26) using hex head bolts (44) with stato-seals (45). Use 'Locktite 262 Permanent Thread Locker' on the bolts. Uniformly tighten referring to Assembly torque requirements chart (Table 1) for proper bolt torque.
- O. Lubricate piston bolt O-ring (30) with 'Dow Corning #112' lubricant and put on piston rod. Assemble piston (25) to piston rod with bolt (33) and lock washer (34). Use 'Locktite 262 Permanent Thread Locker' on bolt threads. Rotate piston before tightening piston bolt to ensure proper seating of O-ring.
- P. Install cylinder gasket or lubricated O-ring (46) in adaptor groove.
- Q. Lubricate piston seal (31) with 'Dow Corning #112' lubricant and install on piston.
- R. Lubricate piston bearing (35) and cylinder (24) with 'Dow Corning #112' lubricant. Hold piston bearing (35) in place on piston (25) and slide cylinder (24) over piston and bearing until cylinder is in contact with gasket / O-ring (46) in adaptor groove. On spring return models substitute one cylinder (24) with cylinder (49) on spring side.
- S. Assemble tie rods (41) on adaptor.
- T. Insert cylinder gasket / O-ring (46) in endcap (27) groove and place endcap over tie rods (41) and on cylinder (24).
- U. Assemble lock washers (43) and hex nuts (HP Models) on tie rods and uniformly tighten. Do not exceed torque values shown in Assembly torque requirements chart (Table 1).

to Assembly torque requirements chart (Table 1).

All models (except S-003 and B-006)

- V. On spring return models; hollow tie rods (50) must be screwed onto long bolts (51) protruding from adaptor (26).
- W. Place cylinder gasket / O-ring (46) in endcap (54). Insert long bolts (51) with flat washer (53) in endcap.
- X. Place spring(s) in cylinder, being sure to nest in piston contours. Mount endcap over extended spring(s) and fasten to hollow tie rods (50) with bolts (51). To prevent galling, lubricate bolts (51) with 'Whitmore's Omnitemp II' grease or equal. Alternately and uniformly tighten bolts (51) in hollow tie rods. Tighten each bolt approximately 6.4 - 12.7 mm [$\frac{1}{4}$ " - $\frac{1}{2}$ "] following the sequence shown in Tie rod tightening sequence (Figure 8) until spring is completely compressed. Be sure that each hollow tie rod slides into the counterbore in the endcap. Do not over tighten bolts. Refer to Assembly torque requirements chart (Table 1).

All models

- Y. Install position indicator (13) and pointer (16), where applicable. Assemble adjusting screws (37), thread seals (36) and jam nuts (38). Lubricate the rubber face of the thread seal with Dow Corning #112 lubricant and install finger tight against the endcap. Tighten the seal approximately one turn so that the rubber begins to bulge beyond the metal portion of the seal.
- Z. Stoke actuator with rated supply air and check for leaks. The thread seal may be tightened up to one additional turn if there is any leakage at the adjusting bolt.

**SPRING RETURN ONLY
(Models S-003 and B-006 only)**

- V. Place cylinder gasket / O-ring (46) in endcap (54).
- W. Place springs in adaptor, being sure to nest in contours. Mount piston (25) over springs and fasten with piston bolt (33) and lock washer (34). Do not over tighten bolts. Refer

MODELS A, B, C AND S PNEUMATIC ACTUATORS

OPERATION AND MAINTENANCE INSTRUCTIONS

ASSEMBLY OF CANTED YOKE ACTUATORS

Canted yoke actuators are assembled the same way as the symmetric yoke actuators except for the following additional instructions for specific models.

Canted yoke actuators have a non-symmetrical piston rod as well as a non-symmetrical yoke. It is important to orient the piston rod with the longer dimension in relation to the yoke as shown in Figure 7C. Note that the finished housing assembly is used for both fail open and fail closed actuators.

(Models 135-1150)

- A. Insert the yoke (2) into the housing (1) and position the yoke in the fully clockwise position (viewed from the thrust plate (13b) side).
- B. Insert the piston rod (4) correctly oriented with the longer dimension as shown in Figure 7C.
- C. Install the thrust pin (9) and roller bearings (10) using generous amounts of Whitmore Omnitemp grease and install both pin retaining rings (11).
- D. Shift the yoke (2) and piston rod (4) so that the thrust pin (11) and roller bearing (10) assembly can be inserted into the yoke slot. The absence of the piston rod bushings (7) and output shaft bushings (5) allows just enough room for this process.
- E. Insert the lower output shaft bushing (5) and retaining ring (12b). This bushing must have a press fit. The integral seal O-ring must be oriented toward the yoke.
- F. Insert the yoke key (6b) into the output shaft (3), then insert the output shaft into the housing (1) and yoke (2) and lower output shaft bushing (5).
- G. Install the upper output shaft bushing (5) over the output shaft and into the housing (5). The bearing must have a press fit. The integral seal O-ring must be oriented toward the yoke.
- H. Install output shaft thrust washer (22), thrust plate gasket (13b) thrust plate (13b), thrust washer (22) and retaining ring (8).
- I. Install pointer adaptor (13) using two socket head cap screws.
- J. Install the thrust plate seal (12), pointer (16) and pointer washer (21).

(Models 1485-7114)

Assembly for these canted yoke actuator models is identical to the symmetric yoke models. However, the yoke (2) must be oriented as shown in Figure 7B. The left and right piston rods are different lengths. Refer to Figure 7C to assure the correct orientation.

11. OPERATING INSTRUCTIONS

Operate the actuator in accordance with the pressure and temperature limits specified on the nameplate. See the appropriate Catalog for technical information.

12. IMPORTANT SAFEGUARDS

CAUTION: *To reduce the risk of injury:*

- Read the entire operation and maintenance instruction manual before installing, operating, or servicing this actuator.
- Inspect the actuator regularly for signs of corrosion and repair immediately.
- Always remove pressure and disconnect power supply before servicing the actuator.
- Keep hands and feet clear of an actuator that is in service.
- Do not disassemble the actuator without reviewing the disassembly procedure in this manual first. This is particularly important that the proper procedure be followed to avoid injury from internal spring power.
- Before attempting to remove an actuator from the equipment it is assembled to, always be sure that spring is in the 'failed' or extended position. Remove any accessory equipment that may cause the spring to be cocked. If there is any doubt that the actuator is in the 'failed' position, remove the air pressure from the actuator and install a long threaded bolt (a bolt that exceeds the length of the cylinder) in place of both travel stops. Once the actuator has been removed from the equipment the long bolts must be removed first before the actuator can be disassembled.
- Repair or replace a damaged actuator immediately.
- Inspect the vent valves on models 1480-2380 during regular maintenance periods. The valves should allow leaking fluids to escape but prevent contaminants from the surrounding atmosphere from entering the actuator. Fluid leaking from the lower valve indicates a valve stem seal leak. Fluid leaking from the upper valve indicates a leaking cylinder seal. If leakage is observed from either valve disassemble and repair the source immediately. Never replace the vent valves with plugs.
- Operate the actuators within the pressure and temperature ranges specified on the nameplate. Otherwise the actuator life may be reduced or serious safety hazards may develop.

MODELS A, B, C AND S PNEUMATIC ACTUATORS

OPERATION AND MAINTENANCE INSTRUCTIONS

13. ADDITIONAL SAFETY INSTRUCTIONS FOR ACTUATORS USED IN A POTENTIALLY EXPLOSIVE ATMOSPHERE UNDER ATEX 94/9/EC

Marking

- ATEX 94/9/EC , Group II, category (2), G

Selection

- Ensure that the equipment is marked with the correct equipment group, category and type of atmosphere for the application and that the safety instructions are followed for each item of the equipment.
- In particular, all items included in an actuator package, including valve, actuator and all accessories should be CE marked to ATEX in the appropriate and / or requested category.

Installation

- The installer must only use tooling appropriate to the working area, see EN 1127-1 Annex A.
- Installation must be carried out at ambient temperature.
- During installation ensure that no metallic shocks / impacts are made to the equipment or the adjacent piping.
- Ensure that the equipment is suitably earthed (grounded) through the pipe or individually.
- The installer should thoroughly follow the operating and safety instructions provided for each individual item of equipment.
- When the valve is to handle hot fluids or fluids where exothermic reactions may take place, the end user must take all the necessary measures to ensure that the hot surface of the valve cannot provide a source of ignition to the surrounding gas, vapour, mist or dust atmosphere.
- Before putting into use or during operation with a dangerous fluid, ensure that no release of the fluid to atmosphere can take place.

Maintenance

- The operator shall ensure that maintenance and testing activities are carried out by competent personnel.
- The operator must ensure that only personnel qualified to work in a potentially hazardous area are allowed to carry out maintenance appropriate to the category of the equipment in use.
- The end user must ensure that only tooling appropriate to the working area is used, see EN 1127-1 Annex A.
- All equipment must only be fitted with manufacturer's original spare parts.

14. ADDITIONAL SAFETY INSTRUCTIONS FOR ACTUATORS USED IN EMERGENCY SHUT-DOWN SERVICE OR IEC 61508 SAFETY INTEGRITY LEVEL (SIL) COMPLIANT INSTALLATIONS

1. The actuator will move a valve to the designated safe position per the actuator design within the specified safety time.
2. The actuator has met the systematic requirements for SIL-3.
3. The actuator is a Type A device with a hardware fault tolerance (HFT) = 0.
4. If the automated partial valve stroke test (PVST) diagnostics is used, the diagnostics time is the PVST test interval.
5. Customer is required to confirm the actuator is operated within the listed temperature limitations shown on page 1.
6. Customers may voluntarily register their actuator by contacting actuator sales department.
7. Actuators should be inspected for proper functioning and signs of deterioration every 100,000 cycles or annually (whichever comes first) under normal operating conditions. Inspect more frequently under severe operating conditions Defects should be repaired promptly.
8. Normal operating conditions are: Air Quality within ANSI/ISA-7.0.01 standards; operating temperature and pressures consistent with the actuator nameplate and catalog limits; environment free from excessive particulates; operating environment consistent with the actuator materials of construction. Under these conditions, actuator life can exceed a million cycles.
9. The recommended minimum operating interval is six months and a partial stroke is acceptable to confirm that the installation is functioning.
10. When an actuator has been repaired or any maintenance is performed, check the actuator for proper function (proof testing). Any failures effecting functional safety should be reported to the Pelham facility.
11. IEC 61508 (SIL) installations should consult the factory to obtain the assessment and FMEDA report, which include failure data, PFDAVG, and other associated statistical data to establish or satisfy SIL level or requirements. This information is available in report MOR 12\04-064 R001 V1 R1 FMEDA.
12. Proof testing of the actuator shall be performed on the interval determined per IEC 61508 / IEC 61511 requirements. A suggested proof test is included in report MOR 12\04-064 R001 V1 R1 FMEDA. No special tools are needed. The report includes the achieved proof test coverage.

13. Service and maintenance on actuators shall only be performed by personnel trained in Safety Integrity Systems (SIS) operations and in the repair and maintenance procedure for actuators.



Biffi reserves the the right to change product designs and specifications without notice.

Biffi Italia S.r.L.

Località Caselle San Pietro, 420, 29017 Fiorenzuola d'Arda (PC) ITALY Ph: +39 (0)523 944 411 E-mail: biffi_italia@biffi.it www.biffi.it